







地平线 BD125-1


























58

59

60





61







64




















109




110



111



112



序 号 Ref.No	零 部 件 代 号 Part No.	零 部 件 名 称	Desctiption	备 注
1	125001001	头罩		
2	125001002	前泥板		
3	125001003	右前上侧板		
4	125001004	左前上侧板		
5	125001005	右前下侧板		
6	125001006	左前下侧板		
7	125001007	尾板		
8	125001008	仪表罩		
9	125001009	右油箱罩		
10	125001010	左油箱罩		
11	125001011	下前板		
12	125001012	右前侧通风口		
13	125001013	左前侧通风口		
14	125001014	右中侧板		
15	125001015	左中侧板		
16	125001016	链罩		
17	125001017	内泥板		
18	125001018	后泥板		
19	125001019	车架		
20	125001020	仪表支架		
21	125001021	发动机上吊板		
22	125001022	单撑		
23	125001023	左右护板支架		
24	125001024	后平叉		



25	125001025	左手把		
26	125001026	右手把		
27	125001027	车架连接摇架		
28	125001028	平叉连接摇架		
29	125001029	上联板		
30	125001030	方向器组件		
31	125001031	钢碗总成		
32	125001032	右前减震		
33	125001033	左前减震		
34	125001034	后中心减震		
35	125001035	前双碟刹泵		
36	125001036	前碟刹盘		
37	125001037	后碟刹泵		
38	125001038	后碟刹盘		
39	125001039	前铝轮		
40	125001040	前轮胎		110/70-17
41	125001041	后铝轮		
42	125001042	后轮胎		140/70-17
43	125001043	仪表总成		
44	125001044	左前转向灯		
45	125001045	右前转向灯		
46	125001046	前大灯		
47	125001047	后左转向灯		
48	125001048	后右转向灯		
49	125001049	尾灯		
50	125001050	牌照灯		

51	125000914	蓄电池		12N9-BS 12V9AH
52	125000907	点火线圈		
53	125000909	电喇叭		
54	125000906	闪光器		
55	125000905	稳压整流器		
56	125000904	点火器		
57	125000903	继电器		
58	125001058	油箱		
59	125000916	消声器		
60	125000915	空滤器		
61	125000901	发动机		
62	125001062	前座垫		
63	125001063	后座垫		
64	125000902	化油器		
65	125001065	套锁总成		
66	125001066	左组合开关		
67	125001067	左把套		
68	125001068	手把装饰球		
69	125001069	右组合开关		
70	125001070	油门转把		
71	125001071	离合器手柄		
72	125001072	前轮轴		
73	125001073	前轮轴套		
74	125001074	前轮轴螺帽		
75	125001075	平叉轴		
76	125001076	平叉轴螺帽		

77	125001077	计数器		
78	125001078	后轮轴		
79	125001079	后轮轴套		
80	125001080	后轮轴螺帽		
81	125001081	平叉侧片		
82	125001082	调链器		
83	125001083	碟刹油管夹		
84	125001084	离合器线		
85	125001085	里程线		
86	125001086	油门线		
87	125001087	风门线		
88	125001088	座垫锁线		
89	125001089	后牌照支架		
90	125001090	单撑弹簧		
91	125001091	平叉橡皮		
92	125001092	里程线固定橡皮		
93	125001093	油箱后橡胶垫		
94	125000911	前侧反射器		
95	125001095	进气管		
96	125001096	消声器抱箍		
97	125001097	油箱前橡胶垫		
98	125000912	后侧反射器		
99	125001099	后视镜		
100	125001100	前变档搁脚		
101	125001101	前脚刹变档		
102	125001102	左后搁脚		

103	125001103	右后搁脚		
104	125000908	补气阀		
105	125000920	碳罐总成		
106	125001106	燃油传感器		
107	125000917	油管		
108	125000918	油开关		
109	125001109	链条		428H-122
110	125001110	发动机尾盖		
111	125001111	后碟刹支架板		
112	125001112	挡风玻璃		
113	125001113	主电缆		
114	125001114	后刹开关线		
115	125001115	电瓶连接线		